

Concept AirTrace 'S' Smoke System



The Concept Air Trace is perfect for situations where a small amount of smoke is required for air tracing applications or in remote locations where no power is available. It is capable of producing short bursts or a steady stream of smoke, if required, for up to 10 minutes on a full battery or up to 1 hour, with the optional mains adaptor and dummy battery. The unit is compact and very simple to use and operates on a 12vDC sealed battery.

The 'S' variant, with a stainless steel cover, is primarily used in clean room applications.

Kit comprises:

AirTrace S smoke generator, battery, charger, 500ml smoke fluid, extension probe and carry case

Optional Extras:

Mains adaptor with dummy battery
Spare Lead Acid sealed battery
NiMH battery

Specification:

Output:
100 cubic feet/minute
Power Consumption:
75 W
Tank Capacity:
110 cc
Battery (supplied):
12V DC/2.3Ah
Consumption:
2 cc/min
Weight:
2.7 kg
Dimensions:
227 x 66 x 81mm

Concept Engineering Limited

7 Woodlands Business Park
Woodlands Park Avenue
Maidenhead, Berks SL6 3UA, UK
Tel +44 (0)1628 825555 Fax +44 (0)1628 826261
Email: info@conceptsmoke.com



www.conceptsmoke.com